




# Dell Studio 1537 RAM Replacement

Replace your faulty or underpowered RAM to breath new life into your Dell Studio 1537 laptop.

Written By: Zach Dylag



## Step 1 — Battery



⚠ Ensure the laptop is turned off and unplugged before attempting to remove any piece.

- Place the laptop lid down so the underside is visible.
- Pull battery release switch and gently pull the battery directly away from the switch.

## Step 2 — Back Cover



- Identify the back cover of the laptop.

## Step 3



- Unscrew and remove all of the 6.0mm screws with a Phillips #1 screwdriver.



## Step 4



- Lift the back cover off of the laptop.



## Step 5 — RAM



- Pull outwards on both of the tabs for one of the RAM slots.

**i** The RAM stick should pop up at an angle after this.

## Step 6



- Pull the RAM stick out of the slot.
- Repeat with the remaining RAM stick.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 01:57:35 AM.